

## Consumer Aftercare Guidelines

### Following Installation:

Please allow 3 days following installation for Protekt® PPF to properly cure before washing or waxing your vehicle. When the average daily temperatures fall below 55 F, please allow 7 days following installation for Protekt PPF to properly cure before washing or waxing your vehicle.

Do not attempt to pierce a water bubble during the curing period as this will cause damage to your film that is not covered by the warranty.

The Product may take up to 30 days to fully cure. It is normal for haze and condensation to be noticeable during this time. Do not attempt to remove any haze/condensation or attempt to address any edge lifting.

If any follow-on work is required to address these concerns, the installing dealer is the only authorized person/entity to perform this work. Contact your dealer with any concerns.

### Protekt PPF Film Care:

A self-healing and stain resistant coating on the surface of the film helps protect it from damage, however, care should be taken to keep your film in good condition.

- Always be sure to hand wash your vehicle with Madico® Endurance™ Rinseless Power Foam Car Wash or similar.
- Ceramic Coating - Many ceramic coatings contain harmful petroleum-based solvents and it is important to not use these products on PPF. Please only use ceramic coatings that use a non-petroleum, neutral carrier on your PPF, like Endurance TruCeramic.
- Avoid automatic or commercial car washes, the use of a high-pressure washer, high powered pressure steam and/or a power washer. \*
- Do not use any abrasive cleaning solutions or materials. \*
- Avoid exposure to thermal shock (sudden excessive heat or cold). \*
- Promptly remove tough stains like insects, tree sap, and/or other contaminants with Madico Endurance Surface Prep or isopropyl alcohol.

*\*These items are not covered by the Madico PPF Warranty and will void the warranty. Please refer to the Madico Protekt PPF warranty for full details.*